



# XEagle Sport

## Main Parts List

Aircraft Body X1




XWatch X1




Propellers X4



Intelligent Battery X1



Battery Charger X1



Power Cable X1




Documents X1



\* This aircraft and its components contain sensitive electronic parts. Do not disassemble them. Please contact FLYPRO or an authorised FLYPRO seller if you have any questions.

# XEagle Sport Accessories


Gimbal Cover X1



16G Micro SD Card X1



Power Plug X1



Magnetic Charging Cable X1



Landing Pads X4

